NOTICE OF CHANGE

INCH-POUND

MIL-STD-348A NOTICE 2 21 July 1992

MILITARY STANDARD

the property of the control of the c

RADIO FREQUENCY CONNECTOR INTERFACES FOR

HIL-C-3643, MIL-C-3650, MIL-C-3655, MIL-C-25516, MIL-C-26637, MIL-C-39012, MIL-C-49142, MIL-A-55339, AND MIL-C-83517

TO ALL HOLDERS OF MIL-STD-348A:

1. THE FOLLOWING PAGES OF MIL-STD-348A ARE NEW OR HAVE BEEN REVISED AND SUPERSEDE THE PAGES LISTED:

NEW PAGE	DATE	SUPERSEDED PAGE	DATE
iii		iii	12 January 1990
iv		iv	12 January 1990
v/vi		V	12 January 1990
SECTION 300		SECTION 300	12 January 1990
310.1		310.1	12 January 1990
310.2		310.2	12 January 1990
310.3/310.4		310.3	12 January 1990
323.1		NEV	
323.2		NEW	
325.1		NEW	
325.2		NEW	

- 2. RETAIN THIS NOTICE AND INSERT BEFORE TABLE OF CONTENTS.
- 3. Holders of MIL-STD-348A will verify that page changes and additions indicated above have been entered. This notice page will be retained as a check sheet. This issuance, together with appended pages, is a separate publication. Each notice is to be retained by stocking points until the military standard is completely revised or canceled.

CONCLUDING MATERIAL

Custodians:
Army - CR
Navy - EC
Air Force - 85

Review activities:
Army - AT, AV, MI
Havy - AS, SH
Air Force - 10, 11, 17, 99
DLA - ES

Preparing activity: Army - CR

Agent: DLA - ES

(Project 5935-3815)

User activities: Nevy - CG, MC

AMSC N/A
<u>DISTRIBUTION_STATEMENT A</u>. Approved for public release; distribution is unlimited.

FSC 5935

CONTENTS

		<u>Page</u>	-
		1	
	1.	SCOPE	
		Purpose	
	1.1		
	1.2	• •	
	2.	REFERENCED DOCUMENTS	
		Government documents	
	2.1	and the second s	
	2.1.1	and the second s	
	2.2 3.	Order of precedence	
	J.		
	3.1	Terms	
	4.	GENERAL REQUIREMENTS	
	5.	DETAILED REQUIREMENTS	
		Gauge tests	
	5.1		
	5.2 5.3		
	5.4		
	5.5	Change effectivity	
	J.J	NATES	,
	6.	NOTES - CONTRACTOR	
	6.1		
	6.2		
	6.3	Subject term (key word) Listing	,
	6.4	Changes from previous issue	
		FIGURES	
		Interface, series TWTNC, coupling nut	. 1
figure	101-1,	Interface, series THTNC, coupling nut	. 2
	101-2.	Interface, series TWENC, no coupling nut	. 1
	102-1.	Interface, series TWBNC, with coupling nut	.2
	102-2. 102-3.	Interface, series TMBNC, coupling nut	د.
	102-3.	Interface, series TWSMC, without coupling nut	. I
	103-1.	Interface, series TWSMC, with coupling nut	ع.
	104-1.		
	104-2.		
	201-1.		
	201-2.		
	202-1.		
	202-2.	Interface, series TRT, pin contact	.1
	301-1.	Interface, series TRT, socket contact	.2
	301-2.	Interface, series BMC, socket contact	. 1
	302-1.	Interface, series C, pin contact	2.2
	302-2.	Interface, series C, socket contact	3.1
	303-1.	Interface, series MHV, pin contact	5.2
	303-2.	Interface, series MMV, socket contact	. 1
	304-1.	Interface, series N, pin contact 300 Interface, series N, socket contact 300	٠.2
	304-2.	Interface, series N, socket contact Interface, series QL, pin contact 305	٠. ١
	305-1.		ة ـ ذ
	305-2.	Interface, series QL, Sucket contact	

Supersedes page fii of Notice 1.

CONTENTS

325-2. Interface, series BNZ, socket contact			Page
306-2. Interface, series ONC, pocket contact 307.1 307-1. Interface, series ONC, poin contact 307.2 308-1. Interface, series OSC, pin contact 308.2 308-2. Interface, series SC, pin contact 309.2 309-2. Interface, series SC, socket contact 309.2 310-1. Interface, series SMA, pin contact 309.2 310-2. Interface, series SMA, pin contact 310.2 310-3. Interface, series SMA, socket contact 310.2 311-1. Interface, series SMB, socket contact 310.3 311-1. Interface, series SMB, socket contact 311.2 312-1. Interface, series SMC, socket contact 312.2 313-1. Interface, series SMC, socket contact 312.2 313-1. Interface, series TMC, pin contact 313.3 313-1. Interface, series TMC, socket contact 313.3 313-1. Interface, series TMC, socket contact 313.2 313-1. Interface, series TMC, socket contact 313.2 313-2. Interface, series TMC, socket contact 313.4 <t< td=""><td>306-1</td><td>Interface series QM, pin contact</td><td>306.1</td></t<>	306-1	Interface series QM, pin contact	306.1
307-1. Interface, series QNC, pin contact 307.2 308-2. Interface, series QSC, pin contact 308.1 308-2. Interface, series QSC, socket contact 308.1 309-2. Interface, series SC, pin contact 309.1 309-2. Interface, series SC, socket contact 309.2 310-1. Interface, series SMA, pin contact 310.2 310-2. Interface, series SMB, pin contact 310.2 310-3. Interface, series SMB, pin contact 310.3 311-1. Interface, series SMC, pin contact 311.2 311-2. Interface, series SMC, pin contact 311.2 312-2. Interface, series TMC, socket contact 312.1 313-2. Interface, series TMC, pin contact 313.2 313-3. Interface, series TMC, pin contact 313.3 313-4. Interface, series TMC, pin contact 313.3 313-2. Interface, series TMC, pin contact 313.3 314-1. Interface, series TMC, pin contact 313.3 313-2. Interface, series SMC, pin contact 313.3 314-1. <td></td> <td>Interface, series QM, socket contact</td> <td>. 306.2</td>		Interface, series QM, socket contact	. 306.2
307-2. Interface, series OSC, pin contact 308.1 308-1. Interface, series OSC, pin contact 308.2 309-2. Interface, series SC, pin contact 309.2 309-2. Interface, series SKA, socket contact 309.2 310-1. Interface, series SMA, pin contact 310.1 310-2. Interface, series SMA, socket contact 310.3 311-1. Interface, series SMB, socket contact 310.3 311-2. Interface, series SMB, socket contact 311.2 312-1. Interface, series SMC, pin contact 311.2 313-1. Interface, series SMC, socket contact 312.2 313-1. Interface, series SMC, socket contact 312.2 313-1. Interface, series SMC, socket contact 313.2 313-1. Interface, series MC, socket contact 313.3 313-3. Interface, series MC, socket contact 313.2 313-3. Interface, series MC, socket contact 313.4 314-1. Interface, series MC, socket contact 314.2 315-2. Interface, series SMC, socket contact 314.2 <tr< td=""><td></td><td>Interface, series QNC, pin contact</td><td>307.1</td></tr<>		Interface, series QNC, pin contact	307.1
308-1. Interface, series QSC, pin contact 308.2 309-2. Interface, series SC, pin contact 309.1 309-1. Interface, series SC, pin contact 309.1 309-2. Interface, series SMA, pin contact 309.2 310-1. Interface, series SMA, pin contact 310.1 310-2. Interface, series SMA, pocket contact 310.3 310-3. Interface, series SMB, pin contact 310.3 311-1. Interface, series SMB, pin contact 311.2 311-2. Interface, series SMC, pin contact 311.2 312-2. Interface, series SMC, pin contact 312.2 313-1. Interface, series TMC, pin contact 313.2 313-2. Interface, series TMC, pin contact 313.3 313-3. Interface, series TMC, pin contact 313.4 314-1. Interface, series TMC, pin contact 313.4 315-2. Interface, series SMY, pin contact 314.1 315-2. Interface, series LC, pin contact 315.2 315-3. Interface, series LC, socket contact 315.2 315-3. Interface, series LC, socket contact 315.2 315-4. Interface, series LC, socket contact 315.4 316-3. Interface, series LC, socket contact 315.6		Interface, series QNC, socket contact	307.2
308-2. Interface, series SC, pocket contact 309.1 309-1. Interface, series SC, socket contact 309.1 310-2. Interface, series SMA, pin contact 309.2 310-2. Interface, series SMA, socket contact 310.2 310-2. Interface, series SMA, socket contact 310.2 310-3. Interface, series SMB, pin contact 311.1 311-1. Interface, series SMB, pin contact 311.1 312-1. Interface, series SMC, pin contact 312.1 312-1. Interface, series SMC, pin contact 312.1 313-1. Interface, series TMC, pin contact 313.3 313-2. Interface, series TMC, pin contact 313.3 313-3. Interface, series TMC, socket contact 313.3 314-2. Interface, series TMC, socket contact 313.3 314-2. Interface, series SMV, socket contact 314.2 315-2. Interface, series LC, pin contact 315.2 315-3. Interface, series LC, socket contact 315.2 315-3. Interface, series LC, socket contact 315.2 315-3. Interface, series LC, socket contact 315.2 315-4. Interface, series LC, socket contact 315.2 315-5. Interface, series LC, socket contact 315.3 </td <td></td> <td>Interface series QSC. pin contact</td> <td>308.1</td>		Interface series QSC. pin contact	308.1
309-1. Interface, series SC, poin contact 309.2 310-1. Interface, series SNA, pin contact 310.3 310-2. Interface, series SNA, pin contact 310.3 310-3. Interface, series SNA, poin contact 310.3 311-1. Interface, series SNB, pin contact 311.3 311-2. Interface, series SNB, socket contact 311.2 312-2. Interface, series SNC, pin contact 312.2 313-1. Interface, series TNC, socket contact 313.2 313-2. Interface, series TNC, socket contact 313.3 313-3. Interface, series TNC, pin contact 313.3 314-1. Interface, series TNCA, pin contact, air interface 313.3 314-1. Interface, series TNCA, pin contact 314.1 314-2. Interface, series SNV, socket contact 314.1 315-3. Interface, series LC, pin contact 315.1 315-1. Interface, series LC, pin contact 315.3 315-2. Interface, series LC, socket contact 315.3 315-3. Interface, series LC, pin contact 315.3 315-4. Interface, series LC, pin contact 315.4 315-5. Interface, series LC, socket contact 315.4 316-6. Interface, series LC, socket contact 315.6		Interface, series QSC, socket contact	308.2
309-2. Interface, series SKA, pin contact 300.1 310-1. Interface, series SKA, pin contact 310.1 310-2. Interface, series SKA, socket contact 310.2 310-3. Interface, series SKA, no contact 310.3 311-1. Interface, series SKB, socket contact 311.1 311-2. Interface, series SKC, pin contact 312.1 312-1. Interface, series SKC, seoket contact 312.1 313-1. Interface, series TKC, pin contact 313.2 313-1. Interface, series TKC, socket contact 313.3 313-2. Interface, series TKC, socket contact 313.3 313-3. Interface, series TKC, socket contact, air interface 313.4 314-1. Interface, series SKY, socket contact, air interface 313.4 314-2. Interface, series SKY, socket contact 314.1 315-3. Interface, series LC, pin contact 315.2 315-3. Interface, series LC, pin contact 315.3 315-3. Interface, series LC, socket contact 315.3 315-5. Interface, series LC, socket contact 315.5 316-1. Interface, series LC, socket contact 315.5 316-2. Interface, conxial environment resistant 316.2 316-3. Interface, series SKA, socket contact 317.2 317-1. In		Interface series SC pin contact	309.1
310-2		Interface series SC. socket contact	309.2
310-2. Interface, series SMA, no contact 310.3 310-3. Interface, series SMB, pin contact 310.3 311-1. Interface, series SMB, pin contact 311.2 312-1. Interface, series SMC, pin contact 312.1 312-2. Interface, series SMC, pin contact 312.1 313-1. Interface, series TMC, pin contact 313.1 313-2. Interface, series TMCA, pin contact, air interface 313.3 313-3. Interface, series TMCA, pin contact, air interface 313.4 314-1. Interface, series SMC, pin contact 314.2 314-2. Interface, series SMC, pin contact 314.2 315-1. Interface, series LC, pin contact 315.2 315-2. Interface, series LC, pin contact 315.2 315-3. Interface, series LC, pin contact 315.2 315-4. Interface, series LC, pin contact 315.2 315-5. Interface, series LC, pin contact 315.4 315-6. Interface, series LC, socket contact 315.5 316-1. Interface, series LC, socket contact 315.5 316-2. Interface, series LC, socket contact 316.1 </td <td></td> <td>Interface, series SMA, pin contact</td> <td>310.1</td>		Interface, series SMA, pin contact	310.1
310-3		Interface, series SMA, socket contact	310.2
311-1. Interface, series SMB, pin contact 311.2 312-1. Interface, series SMC, pin contact 312.1 312-1. Interface, series SMC, pin contact 312.2 313-1. Interface, series TMC, pin contact 313.1 313-1. Interface, series TMC, pin contact 313.3 313-2. Interface, series TMCA, pin contact, air interface 313.3 313-3. Interface, series SMY, pin contact 314.2 314-1. Interface, series SMY, socket contact 314.1 315-2. Interface, series LC, pin contact 315.2 315-3. Interface, series LC, pin contact 315.2 315-3. Interface, series LC, pin contact 315.2 315-3. Interface, series LC, pin contact 315.3 315-4. Interface, series LC, pin contact 315.3 315-5. Interface, series LC, pin contact 315.3 316-1. Interface, series LC, pin contact 315.3 316-1. Interface, series LC, socket contact 315.2 316-2. Interface, series LC, socket contact 316.2 316-3. Interface, coaxial environment resistant 316.3 316-4. Interface, series LC, socket contact 317.2 317-2. Interface, series LC, socket contact 317.2 318-1. Interface, series LC, socket contact		Interface, series SMA, no contact	310.3
311-2. Interface, series SMB, socket contact 311.2 312-1. Interface, series SMC, pin contact 312.1 313-2. Interface, series TMC, socket contact 313.1 313-2. Interface, series TMC, socket contact 313.3 313-3. Interface, series TMCA, pin contact 313.4 313-4. Interface, series SMY, pin contact 314.1 314-1. Interface, series SMY, pin contact 314.2 315-1. Interface, series LC, pin contact 315.3 315-1. Interface, series LC, pin contact 315.2 315-2. Interface, series LC, pin contact 315.2 315-3. Interface, series LC, pin contact 315.3 315-4. Interface, series LC, pin contact 315.4 315-5. Interface, series LC, poin contact 315.5 315-6. Interface, series LC, poin contact 315.5 315-6. Interface, series LC, poin contact 315.5 316-1. Interface, series LC, poin contact 315.5 316-1. Interface, series LC, series LC		Interface, series SMB, pin contact	311.1
312-1. Interface, series SMC, pain contact 312.2 313-1. Interface, series TMC, poin contact 313.1 313-2. Interface, series TMC, pin contact 313.3 313-3. Interface, series TMCA, pin contact 313.3 313-4. Interface, series SMV, pin contact 313.4 314-1. Interface, series SMV, pin contact 314.2 315-2. Interface, series SMV, socket contact 314.2 315-1. Interface, series LC, pin contact 315.1 315-2. Interface, series LC, pin contact 315.3 315-3. Interface, series LC, pin contact 315.3 315-4. Interface, series LC, pin contact 315.3 315-5. Interface, series LC, pin contact 315.4 315-6. Interface, series LC, pin contact 315.6 315-7. Interface, series LC, pin contact 315.6 316-1. Interface, series LC, pin contact 315.6 315-6. Interface, series LC, socket contact 315.6 316-1. Interface, series LC, socket contact 315.6 316-2. Interface, series LC, socket contact 316.2	_	Interface, series SMB, socket contact	311.2
312-2. Interface, series SMC, asocket contact 312.2 313-1. Interface, series TMC, pin contact 313.1 313-2. Interface, series TMCA, pin contact 313.2 313-3. Interface, series TMCA, socket contact 313.3 313-4. Interface, series SMV, pin contact 314.1 314-1. Interface, series SMV, pin contact 314.1 315-2. Interface, series LC, pin contact 315.2 315-3. Interface, series LC, pin contact 315.2 315-3. Interface, series LC, pin contact 315.3 315-4. Interface, series LC, pin contact 315.3 315-5. Interface, series LC, socket contact 315.4 315-6. Interface, series LC, socket contact 315.4 316-1. Interface, series LC, socket contact 315.6 316-2. Interface, coaxial environment resistant 316.1 316-3. Interface, series LC, socket contact 316.3 317-1. Interface, series LT, socket contact 317.2 317-1. Interface, series LT, socket contact 317.2 319-2. Interface, series SMB, pin contact 320.2 <		Interfece, series SMC, pin contact	312.1
313-1. Interface, series TMC, socket contact 313.2 313-2. Interface, series TMCA, pin contact 313.2 313-3. Interface, series TMCA, socket contact, air interface 313.3 313-4. Interface, series TMCA, socket contact 314.1 314-1. Interface, series SMV, pin contact 314.2 315-2. Interface, series LC, pin contact 315.2 315-3. Interface, series LC, pin contact 315.2 315-4. Interface, series LC, pin contact 315.2 315-5. Interface, series LC, pin contact 315.4 315-6. Interface, series LC, pin contact 315.4 316-1. Interface, series LC, pin contact 315.5 316-1. Interface, series LC, pin contact 315.4 316-1. Interface, series LC, socket contact 316.4 316-1. Interface, series LC, socket contact 316.2 316-2. Interface, series LC, socket contact 316.3 316-3. Interface, series LC, socket contact 316.4 316-4. Interface, series LT, socket contact 316.4 317-1. Interface, series LT, socket contact 316.4 </td <td>312-2.</td> <td>Interface, series SNC, secket contact</td> <td>312.2</td>	312-2.	Interface, series SNC, secket contact	312.2
313-2. Interface, series TNC, socket contact 313.3 313-3. Interface, series TNCA, pin contact, air interface 313.4 313-4. Interface, series SHV, pin contact 314.1 314-2. Interface, series SHV, pin contact 314.1 315-3. Interface, series LC, pin contact 315.1 315-3. Interface, series LC, pin contact 315.3 315-4. Interface, series LC, socket contact 315.4 315-5. Interface, series LC, pin contact 315.4 315-6. Interface, series LC, socket contact 315.4 315-6. Interface, series LC, socket contact 315.6 316-1. Interface, series LC, socket contact 315.6 316-2. Interface, series LC, socket contact 316.1 316-3. Interface, coaxial environment resistant 316.1 316-4. Interface, coaxial environment resistant 316.3 317-2. Interface, series HN, socket contact 317.2 318-1. Interface, series HN, socket contact 317.2 318-2. Interface, series SFA, pin contact 318.2 319-1. Interface, series SFA, socket contact 319.2 319-1. Interface, series SFA, socket contact 320.1 320-2. Interface, series SFA, socket contact 320.2 321-3. Interface, series	313-1.	Interface, series TNC, pin contact	313.1
313-3. Interface, series TNCA, pin contact, air interface 313.4 314-1. Interface, series SHV, pin contact 314.1 314-2. Interface, series SHV, socket contact 314.1 315-1. Interface, series LC, pin contact 315.1 315-2. Interface, series LC, pin contact 315.2 315-3. Interface, series LC, pin contact 315.3 315-4. Interface, series LC, pin contact 315.4 315-5. Interface, series LC, pin contact 315.4 315-6. Interface, series LC, pin contact 315.5 316-1. Interface, coexial environment resistant 316.1 316-2. Interface, cooxial environment resistant 316.2 316-3. Interface, cooxial environment resistant 316.3 316-4. Interface, series HN, pin contact 317.1 317-1. Interface, series HN, pin contact 317.1 317-2. Interface, series HN, socket contact 318.1 319-1. Interface, series SSHA, pin contact 318.1 319-2. Interface, series SSHA, pin contact 320.1 320-1. Interface, series SSHB, socket contact 32	313-2.	Interface, series TNC, socket contact	313.2
314-1. Interface, series SHY, poin contact 314.2 315-1. Interface, series SHY, socket contact 315.2 315-2. Interface, series LC, pin contact 315.3 315-3. Interface, series LC, pin contact 315.3 315-4. Interface, series LC, pin contact 315.4 315-5. Interface, series LC, pin contact 315.4 315-6. Interface, series LC, socket contact 315.6 316-1. Interface, coaxial environment resistant 316.1 316-2. Interface, coaxial environment resistant 316.2 316-3. Interface, coaxial environment resistant 316.3 316-4. Interface, coaxial environment resistant 316.4 317-1. Interface, series HN, pin contact 317.2 318-1. Interface, series HN, socket contact 317.2 318-1. Interface, series HN, socket contact 318.1 319-2. Interface, series SNA, pin contact 318.1 319-2. Interface, series SNA, pin contact 319.2 320-1. Interface, series SNA, pin contact 320.1 320-2. Interface, series SNA, pin contact 320.1	313-3.	Interface, series TNCA, pin contact, air interface	313.3
314-1. Interface, series SHY, poin contact 314.2 315-1. Interface, series SHY, socket contact 315.2 315-2. Interface, series LC, pin contact 315.3 315-3. Interface, series LC, pin contact 315.3 315-4. Interface, series LC, pin contact 315.4 315-5. Interface, series LC, pin contact 315.4 315-6. Interface, series LC, socket contact 315.6 316-1. Interface, coaxial environment resistant 316.1 316-2. Interface, coaxial environment resistant 316.2 316-3. Interface, coaxial environment resistant 316.3 316-4. Interface, coaxial environment resistant 316.4 317-1. Interface, series HN, pin contact 317.2 318-1. Interface, series HN, socket contact 317.2 318-1. Interface, series HN, socket contact 318.1 319-2. Interface, series SNA, pin contact 318.1 319-2. Interface, series SNA, pin contact 319.2 320-1. Interface, series SNA, pin contact 320.1 320-1. Interface, series SNA, pin contact 320.1	313-4	Interface, series TNCA, socket contact, air interface	313.4
314-2 Interface, series SHV, socket contact 314.2 315-1 Interface, series LC, pin contact 315.1 315-2 Interface, series LC, pin contact 315.3 315-3 Interface, series LC, pin contact 315.4 315-5 Interface, series LC, pin contact 315.5 315-6 Interface, series LC, socket contact 315.6 316-7 Interface, coaxial environment resistant 316.1 316-1 Interface, coaxial environment resistant 316.3 316-2 Interface, coaxial environment resistant 316.3 317-1 Interface, coaxial environment resistant 316.3 317-2 Interface, series HN, pin contact 317.2 317-1 Interface, series HN, socket contact 317.2 318-1 Interface, series LT, no contact 318.1 319-1 Interface, series LT, socket contact 318.2 319-1 Interface, series SMA, pin contact 319.2 320-1 Interface, series SMA, pin contact 320.1 320-2 Interface, series SMB, pin contact 320.1 321-1 Interface, series BMB, pin contact 321.3	314-1.	Interface, series SHV, pin contact	314.1
315-1. Interface, series LC, poin contact 315.2 315-2. Interface, series LC, poin contact 315.3 315-3. Interface, series LC, poin contact 315.4 315-4. Interface, series LC, socket contact 315.5 315-5. Interface, series LC, socket contact 315.5 316-1. Interface, coexial environment resistent 316.1 316-2. Interface, coaxial environment resistent 316.2 316-3. Interface, coaxial environment resistent 316.3 316-4. Interface, coaxial environment resistent 316.3 316-2. Interface, socket contact 317.1 317-2. Interface, series HN, poin contact 317.1 317-2. Interface, series LT, no contact 318.1 318-1. Interface, series LT, socket contact 318.2 319-1. Interface, series SSMA, pin contact 319.2 320-1. Interface, series SSMA, pin contact 319.2 320-1. Interface, series SSMB, pin contact 320.1 321-1. Interface, series SMB, pin contact 320.2 321-1. Interface, series BMB, socket contact 321.3	314-2.	Interface, series SHV, socket contact	314.2
315-2. Interface, series LC, socket contact 315.3 315-3. Interface, series LC, pin contact 315.3 315-5. Interface, series LC, socket contact 315.5 315-6. Interface, coaxial environment resistant 316.1 316-1. Interface, coaxial environment resistant 316.2 316-2. Interface, coaxial environment resistant 316.2 316-3. Interface, coaxial environment resistant 316.3 317-1. Interface, series HN, pin contact 317.1 317-2. Interface, series HN, pin contact 317.2 318-1. Interface, series LT, no contact 318.2 319-1. Interface, series SSMA, pin contact 319.1 319-2. Interface, series SSMA, pin contact 319.1 319-1. Interface, series SSMB, pin contact 320.1 320-1. Interface, series SSMB, pin contact 320.1 321-2. Interface, series SMB, pin contact 321.2 321-3. Interface, series SMB, socket contact 321.2 322-1. Interface, series BMB, socket contact 321.3 322-2. Interface, series BMB, socket contact 322		Interface, series LC, pin contact	315.1
315-3. Interface, series LC, pin contact 315.3 315-4. Interface, series LC, socket contact 315.4 315-5. Interface, series LC, socket contact 315.5 315-6. Interface, consist environment resistant 316.6 316-1. Interface, consist environment resistant 316.2 316-2. Interface, consist environment resistant 316.3 316-3. Interface, consist environment resistant 316.3 316-4. Interface, consist environment resistant 316.3 317-1. Interface, series HN, pin contact 317.2 317-2. Interface, series HN, socket contact 317.2 318-1. Interface, series LT, socket contact 318.1 319-2. Interface, series SSHA, pin contact 319.2 319-1. Interface, series SSHA, socket contact 320.1 320-2. Interface, series SSHB, pin contact 320.1 321-2. Interface, series BHA, pin contact 321.2 321-3. Interface, series BHB, pin contact 321.2 322-1. Interface, series BHB, pin contact 322.2 323-2. Interface, series BHB, pin contact <	315-2.	Interface, series LC, socket contact	315.2
315-4. Interface, series LC, socket contact 315.5 315-5. Interface, series LC, pocket contact 315.6 316-1. Interface, coaxial environment resistant 316.1 316-2. Interface, coaxial environment resistant 316.2 316-4. Interface, coaxial environment resistant 316.3 316-4. Interface, coaxial environment resistant 316.4 317-1. Interface, series HM, pin contact 317.1 318-1. Interface, series LT, no contact 318.1 318-2. Interface, series LT, no contact 318.2 319-1. Interface, series SSMA, pin contact 319.2 319-1. Interface, series SSMA, pin contact 319.2 320-1. Interface, series SSMB, pin contact 320.1 320-2. Interface, series SMB, pin contact 320.1 321-2. Interface, series BMA, socket contact 321.2 321-3. Interface, series BMB, pin contact 321.3 322-1. Interface, series BMB, socket contact 321.3 322-2. Interface, series BMB, pin contact 323.1 323-1. Interface, series BMB, pin contact 323.2 </td <td>315-3.</td> <td>Interface, series LC, pin contact</td> <td>315.3</td>	315-3.	Interface, series LC, pin contact	315.3
315-5. Interface, series LC, pin contact 315.6 316-1. Interface, coexial environment resistant 316.1 316-2. Interface, coexial environment resistant 316.2 316-3. Interface, coexial environment resistant 316.3 316-4. Interface, coexial environment resistant 316.4 317-1. Interface, series HM, pin contact 317.1 317-2. Interface, series HM, socket contact 317.2 318-1. Interface, series LT, no contact 318.2 319-1. Interface, series SSMA, pin contact 318.2 319-1. Interface, series SSMA, pin contact 319.2 320-1. Interface, series SSMB, pin contact 320.2 320-1. Interface, series SSMB, pin contact 320.2 321-1. Interface, series BMA, pin contact 321.2 321-2. Interface, series BMA, pin contact 321.2 322-1. Interface, series BMB, pin contact 321.2 322-2. Interface, series BMB, pin contact 322.2 323-1. Interface, series BMB, pin contact 323.2 323-2. Interface, series BMC, pin contact 323.2	315-4.	Interface, series LC, socket contact	315.4
315-6. Interface, series LC, socket contact 316.1 316-1. Interface, coaxial environment resistant 316.1 316-2. Interface, coaxial environment resistant 316.3 316-3. Interface, coaxial environment resistant 316.3 316-4. Interface, series HN, pin contact 317.1 317-2. Interface, series HN, socket contact 317.2 318-1. Interface, series LT, no contact 318.1 318-2. Interface, series LT, socket contact 318.2 319-1. Interface, series SSHA, pin contact 319.2 320-1. Interface, series SSHB, socket contact 320.1 320-2. Interface, series SSHB, socket contact 320.1 321-2. Interface, series BMA, pin contact 321.1 321-2. Interface, series BMA, socket contact 321.2 321-3. Interface, series BMB, pin contact 321.3 322-1. Interface, series BMB, pin contact 322.1 322-2. Interface, series BMB, pin contact 322.1 323-1. Interface, series BMB, pin contact 323.2 323-2. Interface, series BMB, pin contact 323.1<	315-5.	Interface, series LC, pin contact	315.5
316-1. Interface, coexial environment resistant 316-2. Interface, coexial environment resistant 316-3. Interface, coexial environment resistant 316-3. 316-4. Interface, coexial environment resistant 316-4. Interface, coexial environment resistant 316-4. 317-1. Interface, series HN, pin contact 317-1. Interface, series HN, pin contact 317-2. Interface, series LT, no contact 318-1. Interface, series LT, no contact 318-2. Interface, series STA, pin contact 319-1. Interface, series STA, pin contact 319-2. Interface, series STA, socket contact 319-2. Interface, series STA, socket contact 320-1. Interface, series STA, pin contact 320-2. Interface, series STA, pin contact 321-2. Interface, series STA, pin contact 321-3. Interface, series BMA, pin contact 321-3. Interface, series BMA, socket contact 322-1. Interface, series BMB, pin contact 322-1. Interface, series BMB, socket contact 322-1. Interface, series BMB, socket contact 322-2. Interface, series BMB, socket contact 323-1. Interface, series BMB, socket contact 323-2. Interface, series BMC, pin contact 323-2. Interface, series BMC, pin contact 325-2. Interface, series BMC, pin contact 325-2. Interface, series BMC, pin contact 401-1. Interface, test connector, series C, socket contact 401-2. Interface, test connector, series C, socket contact 401-3. Interface, test connector, series C, socket contact 402-1. Interface, test connector, series N, pin contact 402-1. Interface, test connector, series N, pin contact 402-1. Interface, test connector, series N, pin contact	315-6.	Interface, series LC, socket contact	315.6
316-2.Interface, coaxial environment resistant316.2316-3.Interface, coaxial environment resistant316.3316-4.Interface, coaxial environment resistant316.4317-1.Interface, series HN, pin contact317.1317-2.Interface, series LT, socket contact317.2318-1.Interface, series LT, socket contact318.1318-2.Interface, series SSMA, pin contact319.1319-1.Interface, series SSMA, pin contact319.1319-2.Interface, series SSMA, socket contact320.1320-1.Interface, series SSMB, pin contact320.1320-2.Interface, series SMA, pin contact320.1321-2.Interface, series BMA, pin contact321.2321-2.Interface, series BMA, socket contact321.2321-2.Interface, series BMA, pin contact321.2322-2.Interface, series BMB, pin contact322.1322-2.Interface, series BMB, pin contact322.1323-2.Interface, series BMC, pin contact323.2323-1.Interface, series BMC, pin contact323.2323-2.Interface, series BMC, socket contact323.2325-2.Interface, series BMZ, socket contact325.1325-2.Interface, test connector, series C, pin contact401.1401-3.Interface, test connector, series C, socket contact401.2402-1.Interface, test connector, series N, pin contact402.1402-1.Interface, test connector, series N, pin contact402.1 <td>316-1.</td> <td>Interface, coexial environment resistant</td> <td>316.1</td>	316-1.	Interface, coexial environment resistant	316.1
316-3. Interface, coaxial environment resistant 316-4. Interface, coaxial environment resistant 316-4. 317-1. Interface, series HN, pin contact 317-1. Interface, series HN, socket contact 317-2. Interface, series HN, socket contact 318-1. Interface, series LT, no contact 318-1. Interface, series LT, socket contact 318-2. Interface, series SSMA, pin contact 319-1. Interface, series SSMA, pin contact 319-2. Interface, series SSMB, pin contact 320-1. Interface, series SSMB, pin contact 320-2. Interface, series SSMB, socket contact 321-1. Interface, series BMA, pin contact 321-2. Interface, series BMA, socket contact 321-2. Interface, series BMB, pin contact 321-3. Interface dimension table, series BMA 322-1. Interface, series BMB, pin contact 322-2. Interface, series BMB, pin contact 322-2. Interface, series BMB, socket contact 323-2. Interface, series BMK, pin contact 323-3. Interface, series BMK, pin contact 323-3. Interface, series BMK, pin contact 323-3. Interface, series BMZ, pin contact 323-3. Interface, series BMZ, socket contact 323-3. Interface, series BMZ, socket contact 323-4. Interface, series BMZ, socket contact 323-6. Interface, series BMZ, socket contact 325-1. Interface, series BMZ, socket contact 325-2. Interface, series BMZ, socket contact 325-2. Interface, test connector, series C, pin contact 401-3. Interface, test connector, series C, socket contact 401-3. Interface, test connector, series C, socket contact 402-1. Interface, test connector, series N, pin contact 402-1. Interface, test connector, series N, pin contact	316-2.	Interface, coaxial environment resistant	316.2
316-4. Interface, coexial environment resistant 316.4 317-1. Interface, series HN, pin contact 317.1 317-2. Interface, series LN, socket contact 318.2 318-1. Interface, series LT, no contact 318.2 319-1. Interface, series SSMA, pin contact 319.1 319-2. Interface, series SSMA, socket contact 319.2 320-1. Interface, series SSMB, pin contact 320.1 320-2. Interface, series SMB, pin contact 320.2 321-1. Interface, series BMA, pin contact 321.2 321-2. Interface, series BMA, socket contact 321.2 322-1. Interface, series BMB, pin contact 322.1 322-2. Interface, series BMB, socket contact 322.1 323-2. Interface, series BMB, socket contact 323.1 323-2. Interface, series BMZ, socket contact 323.1 325-1. Interface, series BMZ, socket contact 323.1 325-2. Interface, series BMZ, socket contact 325.1 325-2. Interface, series BMZ, socket contact 401.1 401-3. Interface, test connector, series C, socket contact	316-3.	Interface, coaxial environment resistant	316.3
317-1. Interface, series HM, poin contact 317.1 318-1. Interface, series LT, no contact 318.1 318-2. Interface, series LT, socket contact 318.2 319-1. Interface, series SSMA, pin contact 319.1 319-2. Interface, series SSMA, socket contact 319.2 320-1. Interface, series SSMB, pin contact 320.1 320-2. Interface, series SMB, pin contact 320.2 321-1. Interface, series BMA, socket contact 321.2 321-2. Interface, series BMA, socket contact 321.2 321-3. Interface, series BMA, socket contact 321.3 322-1. Interface, series BMB, pin contact 322.1 322-2. Interface, series BMB, pin contact 322.1 322-2. Interface, series BMB, socket contact 322.2 323-1. Interface, series BMC, pin contact 323.2 323-2. Interface, series BMZ, pin contact 323.2 325-1. Interface, series BMZ, pin contact 325.2 401-1. Interface, test connector, series C, pin contact 401.1 401-2. Interface, test connector, series C, socket contact		Interface, compial environment resistant	316.4
317-2. Interface, series HN, socket contact 317.2 318-1. Interface, series LT, no contact 318.1 318-2. Interface, series SSMA, pin contact 318.2 319-1. Interface, series SSMA, pin contact 319.2 320-1. Interface, series SSMB, pin contact 320.1 320-2. Interface, series SMB, pin contact 320.2 321-1. Interface, series BMA, pin contact 321.1 321-2. Interface, series BMA, socket contact 321.2 321-3. Interface, series BMB, pin contact 322.1 322-1. Interface, series BMB, socket contact 322.1 322-2. Interface, series BMB, socket contact 322.2 323-2. Interface, series BMK, pin contact 323.2 323-2. Interface, series BMK, socket contact 323.2 325-1. Interface, series BMZ, pin contact 325.1 325-2. Interface, series BMZ, pin contact 325.1 325-2. Interface, test connector, series C, pin contact 401.3 401-3. Interface, test connector, series C, socket contact 401.3 402-1. Interface, test connector, series N, socket		Interface, series HM, pin contact	317.1
318-1. Interface, series LT, no contact	317-2.	Interface, series HN, socket contact	317.2
318-2. Interface, series SSMA, pin contact 319-1. Interface, series SSMA, pin contact 319-2. Interface, series SSMA, socket contact 319-2. Interface, series SSMB, pin contact 320-1. Interface, series SSMB, pin contact 320-2. Interface, series SSMB, socket contact 321-1. Interface, series BMA, pin contact 321-2. Interface, series BMA, socket contact 321-3. Interface dimension table, series BMA 322-1. Interface, series BMB, pin contact 322-2. Interface, series BMB, pin contact 322-3. Interface, series BMB, socket contact 323-1. Interface, series BMB, socket contact 323-2. Interface, series SMK, pin contact 323-2. Interface, series SMK, pin contact 323-2. Interface, series BMZ, pin contact 323-2. Interface, series BMZ, socket contact 325-2. Interface, series BMZ, socket contact 325-2. Interface, test connector, series C, pin contact 401-1. Interface, test connector, series C 401-3. Interface, test connector, series C 401-3. Interface, test connector, series C 402-1. Interface, test connector, series N, pin contact 402-1. Interface, test connector, series N, pin contact 402-2. Interface, test connector, series N, pin contact 402-2. Interface, test connector, series N, pin contact 402-2. Interface, test connector, series N, socket contact 402-2.	318-1.	Interface, series LT, no contact	318.1
319-1.Interface, series SSMA, pin contact319.1319-2.Interface, series SSMB, socket contact320.1320-1.Interface, series SSMB, pin contact320.1320-2.Interface, series BMA, pin contact321.2321-1.Interface, series BMA, socket contact321.2321-2.Interface dimension table, series BMA321.3322-1.Interface, series BMB, pin contact322.1322-2.Interface, series BMB, pin contact322.2323-1.Interface, series BMB, socket contact323.1323-2.Interface, series BMK, pin contact323.1323-2.Interface, series BMZ, pin contact323.1325-1.Interface, series BMZ, pin contact325.1325-2.Interface, series BMZ, socket contact325.1325-2.Interface, test connector, series C, pin contact401.1401-1.Interface, test connector, series C, socket contact401.2401-3.Interface, test connector, series C401.2402-1.Interface, test connector, series N, pin contact402.1402-2.Interface, test connector, series N, socket contact402.1	318-2.	Interface, series LT, socket contact	318.2
319-2. Interface, series SSMA, socket contact 320-1. Interface, series SSMB, pin contact 320-2. Interface, series SSMB, socket contact 320-2. Interface, series BMA, pin contact 321-1. Interface, series BMA, pin contact 321-2. Interface dimension table, series BMA 321-3. Interface dimension table, series BMA 322-1. Interface, series BMB, pin contact 322-2. Interface, series BMB, pin contact 322-2. Interface, series BMB, pin contact 323-1. Interface, series BME, socket contact 323-2. Interface, series BME, socket contact 323-2. Interface, series BME, pin contact 323-2. Interface, series BME, pin contact 325-1. Interface, series BME, pin contact 325-2. Interface, series BME, pin contact 325-2. Interface, test connector, series C, pin contact 401-1. Interface, test connector, series C, socket contact 401-2. Interface, test connector, series C 401-3. Interface, test connector, series C 402-1. Interface, test connector, series N, pin contact 402-1. Interface, test connector, series N, pin contact 402-2. Interface, test connector, series N, socket contact 402-2.		Interface, series SSMA, pin contact	319.1
320-1. Interface, series SSMB, pin contact	319-2.	Interface, series SSMA, socket contact	319.2
320-2. Interface, series SMB, socket contact 321-1. Interface, series BMA, pin contact 321-2. Interface, series BMA, socket contact 321-3. Interface dimension table, series BMA 322-1. Interface, series BMB, pin contact 322-2. Interface, series BMB, socket contact 323-1. Interface, series BMB, socket contact 323-1. Interface, series SMK, pin contact 323-2. Interface, series SMK, pin contact 323-2. Interface, series BMZ, pin contact 323-1. Interface, series BMZ, pin contact 325-2. Interface, series BMZ, pin contact 325-2. Interface, series BMZ, socket contact 325-2. Interface, test connector, series C, pin contact 401-1. Interface, test connector, series C, socket contact 401-2. Interface, test connector, series C 401-3. Interface, test connector, series C 402-1. Interface, test connector, series N, pin contact 402-1. Interface, test connector, series N, pin contact 402-2. Interface, test connector, series N, pin contact 402-2.	320-1.	Interface, series SSMB, pin contact	320.1
321-1. Interface, series BMA, pin contact	320-2.	Interface, series SSMB, socket contact	320.2
321-2. Interface, series BMA, socket contact 321-3. Interface dimension table, series BMA 321-3. Interface, series BMB, pin contact 322-1. Interface, series BMB, pin contact 322-2. Interface, series BMB, socket contact 323-1. Interface, series SMK, pin contact 323-2. Interface, series SMK, socket contact 323-2. Interface, series BMZ, pin contact 325-1. Interface, series BMZ, pin contact 325-2. Interface, series BMZ, socket contact 401-1. Interface, test connector, series C, pin contact 401-2. Interface, test connector, series C 401-3. Interface, test connector, series C 402-1. Interface, test connector, series N, pin contact 402-2. Interface, test connector, series N, socket contact 402-2.	321-1.	Interface, series BMA, pin contact	321.1
321-3. Interface dimension table, series BMA	321-2.	Interface, series BMA, socket contact	321.2
322-1. Interface, series BMB, pin contact 322.1 322-2. Interface, series BMB, socket contact 322.2 323-1. Interface, series SMK, pin contact 323.1 323-2. Interface, series BMZ, pin contact 325.1 325-1. Interface, series BMZ, pin contact 325.1 325-2. Interface, series BMZ, sooket contact 325.2 401-1. Interface, test connector, series C, pin contact 401.2 401-2. Interface, test connector, series C, socket contact 401.3 402-1. Interface, test connector, series M, pin contact 402.1 402-2. Interface, test connector, series M, pin contact 402.2	321-3.	Interface dimension table, series BMA	321.3
322-2. Interface, series SMB, socket contact	322-1.	Interface, series BMB, pin contact	322.1
323-1. Interface, series SMK, pin contact		Interface, series BMB, socket contact	322.2
323-2. Interface, series SMK, socket contact		Interface, series SMK, pin contact	323.1
325-1. Interface, series BMZ, pin contact		Interface, series SMK, socket contact	323.Z
325-2. Interface, series BMZ, socket contact	325-1.	Interface, series BMZ, pin contact	325.1
401-1. Interface, test connector, series C, pin contact		Interface, series BMI, socket contact	325.2
401-2. Interface, test connector, series C, socket contact		Interface, test connector, seriés C, pin contact	401.1
401-3. Interface, mated test connector, series C	401-2.	Interface, test connector, series C, socket contact	401.2
402-1. Interface, test connector, series N, pin contact	401-3.	Interface, mated test connector, series C	401.3
402-2. Interface, test connector, series N. socket contact	402-1.	Interface, test connector, series N, pin contact	402.1
402-3. Interface, mated test connector, series N		Interface test connector, series N. socket contact	402.2
	402-3.	Interface, mated test connector, series N	402.3

Supersedes page iv of Notice 1.

CONTENTS

		Page
403-1.	Interface, test connector, series SC, pin contact	403.1
403-2.	Interface, test connector, series SC, socket contact	403.2
403-3.	Interface, mated test connector, series SC	403.3
404-1.	Interface, test connector, series BNC, pin contact	404.1
404-2.	Interface, test connector, series BNC, socket contact	404.2
404-3.	1 =	404.3
405-1.	Interface, test connector, series SMA, pin contact	
405-2.	Interface, test connector, series SMA, socket contact	
405-3.	Interface, mated test connector, series SMA	405.3
406-1.	Interface, test connector, series TNC, pin contact	406.1
406-2.	Interface, test connector, series TNC, socket contact	
406-3.	Interface, mated test connector, series TNC	
407-1.	Interface, test connector, series SMB, pin contact	407.1
407-2	Interface, test connector, series SMB, socket contact	407.2
407-3.	Interface, mated test connector, series SMB	407.3
408-1.	Interface, test connector, series SMC, pin contact	408.1
408-2.	Interface, test connector, series SMC, socket contact	
408-3.	Interface, mated test connector, series SMC	
409-1.	Interface, test connector, series QNC, pin contact	
409-2.	Interface, test connector, series QNC, socket contact	409 2
	Gap of mated standard test connector, series QNC	400 T
409-3.		
410-1.	Interface, test connector, series QSC, pin contact	
410-2.	Interface, test connector, series QSC, socket contact	410.2
410-3.	Gap of mated standard test connector, series QSC	410.3


Supersedes page v of Notice 1.


SECTION 300

Interface Dimensions for MIL-C-3643, MIL-C-3650, MIL-C-26637, MIL-C-39012, MIL-A-55339, and MIL-C-83517

Section 301	Series BNC
Section 302	Series C
Section 303	Series MHV
Section 304	Series N
Section 305	Series QL
Section 306	Series QM
Section 307	Series QMC
Section 308	Series QSC
Section 309	Series SC
Section 310	Series SMA
Section 317	Series SMB
Section 312	Series SMC
Section 313	Series TNC and TNCA
Section 314	Series SHV
Section 315	Series LC
Section 316	Environment resistant
Section 317	Series HN
Section 318	Series LT
Section 319	Series SSMA
Section 320	Series SSMB
Section 321	Series BMA
Section 322	Series BMB
Section 323	Series SMK
Section 324 .	Reserved for 2.4 mm
Section 325	Series BMZ

Supersedes section 300 of Notice 1.






- Dimensions are in inches.
- Metric equivalents are given for general information only. Connector interfaces (after connector mating) shall be kept free from dust and moisture.
- 4. May extend throughout the full length of the coupling nut.

FIGURE 310-1. Interface, series SMA, pin contact.


Supersedes page 310.1 of Notice 1.



- 1. Dimensions are in inches.
- 2. Metric equivalents are given for general information only.
- Previously qualified parts utilizing a .030 inch maximum contact recession are not acceptable for Government procurement. Caution should be exercised to determine whether a .030 inch recession design is being used during maintenance and part replacement.
- 4. Clearance for mating connector coupling nut.
- Dimension to meet VSWR, mating characteristics, and connector durability when mated with a .0355 - .0370 diameter pin

FIGURE 310-2. Interface, series SMA, socket contact.

Supersedes page 310.2 of Notice 1.




Inches	1001
.000	0.00
.003	0.08
.010	0.25
.015	0.38
.045	1.14
.130	3.30
. 135	3.43
.150	3.81
.1808	4.59
.250	6.35
.309	7.85
.315	8.00


- 1. Dimensions are in inches.
- 2. Hetric equivalents are given for general information only.
- 3. Reference MIL-C-39012/92 for cable stripping dimensions.

FIGURE 301-3. Interface, series SMA, no contact.

Supersedes page 310.3 of Notice 1.


310.3/310.4






- 1. Dimensions are in inches.
- 2. Metric equivalents are given for general information only.
- 3. The location of the contact support bead shall not extend beyond the reference plane.

FIGURE 323-1. <u>Interface, series SMK, pin contact</u>.



- 1. Dimensions are in inches.
- 2. Metric equivalents are given for general information only.
- 3. Unless otherwise specified, tolerances are $\pm .005$.


FIGURE 323-2. Interface, series SMK, socket contact.



- 1. Dimensions are in inches.
- 2. Metric equivalents are given for general information only.

FIGURE 325-1. Interface, series BMZ, pin contact.

HIL-STD-348A NOTICE 2



Inches	profession (
.000	0.00
.010	0.25
.062	1.57
.070	1.78
.087	2.21
.095	2.31
. 130	3.30
. 131	3.33
. 182	4.62
.188	4.78

- 1. Dimensions are in inches.
- 2. Metric equivalents are given for general information only.

FIGURE 325-2. Interface, series BMZ, socket contact.